


Installing the Battery in a Bosch Rexroth RCU


Bosch Rexroth RCU



Front side



Rear side



[sources: Rexroth]

The battery is used so that even when the tractor is switched off, the RCU is ready for operation and can send and receive data.



- (1) The battery is installed at the front of the RCU.



- (2) To remove the front cover a screwdriver can be used.



- (3) The battery compartment is on the left side.



- (4) Insert the battery into the battery compartment so that the connecting cables are on the right-hand side.
- (5) Plug in the connecting cables as shown in the picture.



- (6) Close the case by carefully pressing the front cover onto the case.