

Trimble GFX series (GFX-350, GFX-750, XCN-1050¹⁾)

GFX 750




[sources: Trimble]

¹⁾ XCN-1050 is a GFX-750 distributed by CNH.


Disable / Enable ISOBUS Task Controller (TC)

To run a NEVONEX Digital Service, NEVONEX must be the task controller (TC) and all other task controllers must be disabled. If it is not possible to disable a TC, the function instance of the TC must be increased. For more information on ISOBUS, see “Cheatsheet_ISOBUS_Info”.

The ISOBUS TC can be disabled in the ISOBUS Settings.



(1) Select “Settings” on the start screen



(2) Select “ISOBUS”
(3) Disable the Task Controller

[sources: NEVONEX]